

Installation:

It is suggested that Roman 880 pre-mixed heavy duty clear adhesive (or equivalent) be used to install Craft Wallcovering panels. Paste with a soft brush or roller. Time your application of paste carefully to avoid sections drying before the pasting is complete on the entire panel.

While a table cut method is suggested for most of our wallcovering, a test cut is recommended prior to installation for more heavily textured patterns. Excess paste should be delicately wiped from the design surface of the panels with a lightly damp cloth. A soft hair smoother (i.e., Corona Wallpaper Smoother Brush) is suggested to apply this product.

*Plastic sweeps or smoothers are never recommended for the application of Craft Wallcovering designs.

Variations Disclaimer: The handmade nature of Craft Wallcovering designs means variances in color and texture are not defects, but part of the inherent artisanal nature of our wallcovering adding to its bespoke appeal and beauty.